









CHASE -TREND-(18110070-01)


XXXLutz KG

Roemerstrasse 39

AT-4600 Wels,Austria

Info@xxxlutz.at




A		x 2
B		x 1
C		x 1
D		x 2
E		x 2
F		x10
G		x4
H		x 1




CHASE -TREND-(18110070-01)

XXXLutz KG

Roemerstrasse 39 AT-4600 Wels,Austria Info@xxxlutz.at

A		x 1
B		x 2
C		x 2



tool required:



use a drill to make a hole on the wall ,use hammer to beat anchor to the hole and then screw go through the product before into the anchor

ENGLISH

IMPORTANT : Retain for future reference, read carefully.

Use : Product for domestic use. Indoor use only.

WARNING – Do not sit on the product. Do not stand on the product.

WARNING – Do not place heavy objects on this product. Maximum load: 15 kgs.

Do not place bulky objects on this product.

WARNING- In order to prevent overturning ,this product must be used with the wall attachment device provided,the products backside includes two hooks which shall be attached to the wall using screws and anchor ,installation shall be carried out exactly according to the manufacture's instructions-otherwise a safety risk can occur if incorrectly installed .

Maintenance and cleaning : Wipe with a damp cloth. Finish by wiping with a dry cloth.