









Assemble instruction

FOSCO


27980041/04






A	×30	B	×30	C	×7	D	×8	E	×12	F	×8	G	×24	H	×118
															
M6*35mm		φ15mm		M7*50mm		M6*50mm		M6*60mm				φ8*30mm		φ3.5*14mm	
I	×12	J	×6	K	×6	L	×6	M	×14	N	×4	O	×4	P	×1
															
φ4*35mm				340mm		340mm								M4	
Q	×4	R	×16	S	×12	T	×2	U	×2	V	×2	W	×1	X	×2
															
										φ4*45mm					
Y	×4														
															


1





2




3




A	×6	B	×10	G	×10	M	×2
							
M6*35mm		φ15mm		φ8*30mm			

4





5




C	x1	P	x1
			
M7*50mm		M4	

6





B	x4	C	x6	G	x10	Y	x4	P	x1
									
ø15mm		M7*50mm		ø8*30mm				M4	

7




8









H	x24	O	x4	W	x1
					
ø3.5*14mm					




H	x16	R	x16	T	x2	U	x2	V	x2
									
ø3.5*14mm								ø4*45mm	



13






14



S	x12
	







15



H	×13
	
ø3.5*14mm	

J	×1	Q	×4	X	×2
					

16



H	×26	J	×2
			
ø3.5*14mm			