


25400226-01

LILLI

Assembly Instruction


AUFBAUANLEITUNG/Navod/Instruktioner



Ax1PC	Bx1PC	Cx2PCS	Dx2PCS	Ex2PCS	Fx2PCS	Gx2PCS	Kx4PCS
Hx2PCS	Ix2PCS	Jx6PCS	Lx2PCS	M6x35mm ax30PCS	M6x10mm bx12PCS	M4x10mm cx24PCS	4mm dx1PC
				ex2PCS	fx2PCS	gx2PCS	M4x30mm gx2PCS


1

Ex2PCS
Fx2PCS
Gx2PCS
Hx2PCS
Ix2PCS
ax8PCS
M6x35mm
dx1PC
4mm




2

Ax1PC
Cx2PCS
Dx2PCS
ax8PCS
M6x35mm
dx1PC
4mm




3

Jx6PCS
ax6PCS
M6x35mm
bx12PCS
M6x10mm
dx1PC
4mm




4

Bx1PC
ax8PCS
M6x35mm
dx1PC
4mm



5

Kx4PCS
Lx2PC
cx24PCS
M4x10mm



6

ex2PCS
fx2PCS
gx2PCS
M4x30mm

