

ASSEMBLY INSTRUCTION

Greta dining chair








ASSEMBLY INSTRUCTION








Size of assembled product




PART LIST

01	02	03	04	05
				
Front leg frame 1 pc	Right side upright 1 pc	Left side upright 1 pc	Rear leg frame 1 pc	Seat panel 1 pc


HARDWARE

A	B	C	D
			
Fully threaded bolt 4 pcs	nut 4 pcs	M8 flat washer 4 pcs	M8 spring washer 4 pcs
E	**F**	**G**	**H**
			
Halfmoon washer 4 pcs	Wood dowel 8 pcs	Threaded bolt 4 pcs	M6 flat washer 4 pcs
I	**J**	**K**	**L**
			
M6 spring washer 4 pcs	Spanner 1 pc	Hex key 1 pc	Felt Pad 4 pcs

ASSEMBLY


1
01
A
F
2
02
03
Arrow
shows front.
3
B
C
D
E
J
80%
4
A
F
04
5
6
100%
B
C
D
E
J
100%

ASSEMBLY



20840021-02
Mömax
BDSK Handels GmbH & Co. KG
Mergentheim er Straße 59,DE- 97084 Würzburg
Germany
info@moemax.at

