




04310041/01


XXXLutz KG
Roemerstrasse 39
AT-4600 Wels

möma



A	x1	B	x1	C	Lx1Rx1	D	x1	E	x1	F	x1
G	x1	H	x5	I	x4	J	x6	K	x3	L	x2
					M6*25mm		M6*35mm		M8*20mm		M6*20mm
M	x6	N	x1								
	M6		M5								





For domestic use only. (EN)
Nur für den Haushaltsgebrauch. (DE)
Pouze pro používání v domácnosti. (CZ)
Endast för hushållsbruk. (SE)
Len na používanie v domácnosti. (SK)
Samo za domačo uporabo. (SI)
Kizárólag háztartási használatra alkalmas. (HU)
Samo za korištenje u kućanstvu. (HR)
Само за домашна употреба. (BGR)
Doar pentru uz casnic. (RO)
Réserve à un usage domestique uniquement. (FR)
Tylko do użytku domowego. (PL)
Prodotto destinato al solo uso domestico. (IT)
Isključivo za upotrebu u domaćinstvu. (RS)

