

Modell 1175 | 1176

Inhalt / packing list:



- | | |
|---|------------|
| A) Sitz / seat | 1 pc |
| B) Gestell / frame | 1 pc |
| C) Schrauben / screws: | |
| 1175: Schrauben lang 35 mm (vorne) / long screws 35 mm (front) | |
| + kurze Schrauben 20 mm (hinten) / short screws 20 mm (back) | 2 pcs each |
| 1176: Schrauben lang 35 mm + Unterlegscheiben groß (vorne) / long screws 35 mm + big spacers (front) | |
| + kurze Schrauben 25 mm + Unterlegscheiben klein (hinten) / | |
| short screws 25 mm + small spacers (back) | 2pcs each |

Aufbau / assembling:

1175



1176



**max. Belastbarkeit
(in kg)**



Sitzschale umdrehen und auf eine geeignete Unterlage stellen. Gestell über die Muffen in der Sitzschale legen. Mit beiliegendem Innensechskantschlüssel die vier Schrauben handfest einschrauben.

Turn the seat around and place it on a suitable stable base. Position the frame above the sleeves of the seat.

Hand-tighten the screws with the enclosed allen key.