








Assembly Instructions

15024 - 188
Gola Desk









1




2



3






B




X24

4



C



X16

E





X4

J




X2




5







6




7



8



9




L







X4



10




11




12



13



14



OK