



**996153**

**230V/50Hz ~**


- 1xLED-Board 48V DC/24W
- 1xLED-Board 39V DC/19,5W
- 1xLED-Board 27V DC/13,5W

<p><b>LED</b></p> <p>24W 2.760lm 62W 2.750 lm 25.000 h t Tk 15.000 x &lt;0,5s</p> <p>27 kWh/1000h</p>	<p><b>LED</b></p> <p>19,5 W 2.243lm 62 W 2.750 lm 25.000 h t Tk 15.000 x &lt;0,5s</p> <p>22 kWh/1000h</p>	<p><b>LED</b></p> <p>13,5 W 1.553lm 62 W 2.750 lm 25.000 h t Tk 15.000 x &lt;0,5s</p> <p>15 kWh/1000h</p>






b)




Функция на регулиране на светлинния поток	Funkce ztlumení
22	Dimm-Funktion
OK	Dämpfningsfunktion
EST	Funció reguladora
-	Hämarduse funktsioon
FIN	Fonction variateur
GB	Himmennyksen toiminto
GR	Dimmer function
H	Λειτουργία μετρισμού φωτισμού
HR	Fénytömpítő funkció
T	Funkcija prigušivanja
V	Funzione di regolazione
NL	Priemdymo funkcija
S	Spilgiuma samazināšanas funkcija
PL	Dimmfunktions
RO	Dimfunctie
RUS	Função de regulação de intensidade da luz
S	Funkcija sčiemiania
SK	Functie de micșorare a lumini
SL	Функция диммирования
SRB	Dimfunktion
TR	funkcia stnielenia
	Funkcija zatemnení
	funkcija zatamnjivanja
	Kaartima funktsiooni



BG	Caerńostta zapamietena
CZ	Jas uložen
D	Helligkeit gespeichert
DK	Iystyrke gemt
E	La claridad se almacenó
EST	Heledus on salvestatud
F	Luminosité mis en mémoire
FIN	Kirkkaus on tallennettu
GB	brightness level saved
GR	Εξουκόνημη φωτεινότητας
H	Világosság tárolva
HR	Pohranjena svijetloća
I	Luminosità salvata
LT	Šviesumas išsaugotas
LV	Spīgtuma pakāpe saglabāta
N	Lyset begynner å dimme
NL	Helderheid opgeslagen
P	Brillo está memorizado
PL	Zapisano poziom jasności
RO	Luminositate memorata
RUS	Яркость сохранена
S	Ijusystyrkan sparades
SK	Jas uložený
SLO	svetlost shranjena
SRB	osvetljenost je memorisana



Лампата започва да регулира светлинния поток	Světlo se začne ztlumovat	Leuchte beginnt zu dimmen	Lampen begynder at aftage i styrke	La lámpara comienza a regular	Valgus hakkab hämarduma	La lumière commence à baisser	Valo alkaa himmentymään	light starts to dim	To φως αρχίζει να εξασθενεί	A lámpa fénye tömpülni kezd	Svetilo se počinje prigušivati	La luminosità inizia a ridursi	Šviesos priemonėta	Lampa sāk samazināt spīdumu	Lyset begynner å dimme	Lamp beginnt te dimmen	A lámpada começa a regular a intensidade da luz	Lampa zaczyna ściemniać się	Lampa începe să reducă lumina
--	---------------------------	---------------------------	------------------------------------	-------------------------------	-------------------------	-------------------------------	-------------------------	---------------------	-----------------------------	-----------------------------	--------------------------------	--------------------------------	--------------------	-----------------------------	------------------------	------------------------	---	-----------------------------	-------------------------------



BG	Caerfnoshta zapamešena
CZ	Jas uložen
D	Helligkeit gespeichert
DK	Ilystyrke gemt
E	La claridad se almacenó
EST	Heledus on salvestatud
F	Luminosité misé en mémoire
FIN	Kirkkaus on tallennettu
GB	brightness level saved
GR	Εξουκόνηση φωτεινότητας
H	Világosság tárolva
HR	Pohranjena svijetloča
I	Luminosità salvata
LT	Šviesumas išsaugotas
LV	Spīgtuma pakāpe saglabāta
N	Lyset begynner å dimme
NL	Helderheid opgeslagen
P	Brillo está memorizado
PL	Zapisano poziom jasności
RO	Luminositate memorata
RUS	Яркость сохранена
S	Ijusystyrkan sparades
SK	Jas uložený
SLO	svetlost shranjena
SRB	osvetljenost je memorisana