







## ASSEMBLY INSTRUCTIONS

Items : 20140089/01 - 20140089/02 - 20140089/03 - 20140089/04

Please read instructions carefully. Remove all wrapping material, staples and packing straps from the carton, see hardware and Furniture Parts List for guidance. Be sure you have all parts before you start assembling , place all wooden furniture parts on a clean and flat soft surface, such as carpet or a rug to prevent from being scratched.



### HARDWARE LIST


ITEM	GRAPHICS	QTY
A	BOLTS M8x35 	16
B	WASHER ( 1 x Ø9 x Ø18 ) 	16
C	Allen Key 	01
D	WOODEN Ø8 x 20 	04
E	WOOD SCREW M4 x 25 	32

### LIST OF WOOD PARTS

ITEM	DESCRIPTION	QTY
1	LEG	04
2	TOP	01
3	WOODEN SUPPORT PANEL	02
4	IRON SUPPORT	01


#### FOR ASSEMBLY

- First, check the contents to make sure that nothing is missing.
- Sort out the parts and fittings as shown. Assemble product step by step.
- It is preferable to rest the product on a soft surface to avoid damage during assembly.
- Do not overtighten screws and fittings.
- Re-tighten all screws and fittings periodically.




**ASSEMBLY INSTRUCTIONS**

**STEP 1**




**STEP 2**



## ASSEMBLY INSTRUCTIONS

### STEP 3



### STEP 4

