


# ASSEMBLY INSTRUCTION



DE - MONTAGEANWEISUNG  
FR - INSTRUCTIONS DE MONTAGE  
DK - MONTAGEVEJLEDNING  
CZ - NÁVOD K MONTÁŽI  
ES - INSTRUCCIONES DE MONTAJE  
FI - ASENNUSOHJE

HR - UPUTE ZA MONTAŽU  
SE - MONTERINGSANVISNING  
SI - NAVODILA ZA MONTAŽO  
TR - MONTAJ TALIMATI  
NO - MONTASJEANVISNING  
IT - ISTRUZIONI DI MONTAGGIO


GR - ΟΔΗΓΙΑ ΣΥΝΑΡΜΟΛΟΓΗΣΗΣ  
NL - MONTAGE INSTRUCTIE  
PT - INSTRUÇÕES DE MONTAGEM  
PL - INSTRUKCJA MONTAŻU  
HU - SZERELÉSI UTASÍTÁS



20 min



HW-ST-01-168 (4 x 17)




HW-ST-01-168 (4 x 17)



HW-ST-02-021 (6 x 20)




HW-ST-04-060 (48 x 30 x 8)



HW-ST-02-290 (8 x 35)




HW-ST-18-001 (4 x 98)




HW-ST-07-062 (8.5x12.5x1.5)




HW-ST-18-007 (13 x 88)




HW-ST-07-044 (8.5x18x1)




A x1 SU-TB-AS-0349



B x1 SU-TB-TF-1023



C x1 C-A-TB-SU-0889



D x4 SU-TB-LF-1432

