


ASSEMBLING INSTRUCTION

26870345-05




Hardware:


Letter	Piece	Number	Letter	Piece	Number
A	 6x35mm	12pcs	J		1pc
B	 8x30mm	26pcs	K		4pcs
C	 15x12mm	12pcs	L		2sets
D	 5x40mm	6pcs	M		1pc
E	 6x30mm	10pcs	N		8pcs
F	 6x12mm	4pcs	P	 6x40mm	4pcs
G	 3x12mm	4pcs	Q		8sets
H		1pc	R	 4x12mm	12pcs
I		2pcs			

Using Cam Lock and Quickfit




QUICKFIT



CAM LOCK



Tools Required



CAUTION: Do not use tools other than those required, as this can damage your new item.

NOTE

- Please check you have all hardware before assembling.
- If you are missing any hardware, please contact the store of purchase.
- Please ensure you have the name of the item, required hardware part and quantity.
- Please retain your receipt as proof of purchase to validate your warranty.

CAUTION


- Do not tighten screws before all screws are in the right place.
- Do not use this product unless all bolts, screws and knobs are firmly secured.
- Check that all bolts, screws and knobs are securely tightened at least every 4 months.

WARNING


- If parts are missing, broken, damaged or worn stop using the product until all repairs are made using manufacturer authorised parts.
- Failure to follow these warnings could result in serious injury.

DANGER

- CHILDREN MUST BE SUPERVISED.




①




-  (A)x9pcs
-  (L)x2sets

②



-  (A)x3pcs
-  (G)x2pcs
-  (H)x1pc


3



 (B)x6pcs

 (C)x2pcs


4



 (B)x6pcs

 (C)x2pcs


⑤



 (B)x6pcs

 (C)x2pcs

⑥




 (B)x6pcs

 (D)x6pcs

 (M)x1pc

7




(P)x4pcs

(F)x4pcs

(M)x1pc


8




(E)x10pcs

(M)x1pc

9




10



 (B)x6pcs


 (C)x6pcs


11




-  (K)x4pcs
-  (Q)x8sets

12




-  (G)x2pcs
-  (R)x4pcs
-  (I)x2pcs
-  (J)x1pc

13



(R)x8pcs

14



(N)x8pcs

