




INSTRUCTION SHEET

22240024-01



x1




Ax1



Bx2




Cx1




Dx2



Ex1




Fx1




Gx1




Jx1




Kx1




Lx1




Mx1



Nx4




Hx1



Ix1



Ox2



Px1

Ø4x25mm



ax10

Ø3x12mm



bx21



cx1



dx1



ex1



fx2



gx2



hx14



ix16



jx4




kx1



lx2



mx2



nx1



Ø2.5x10mm

ox12



px2

Ø3x14mm










qx2






rx4




Step 1





Step 2




Step 3





Step 4





Step 5





Step 6




Step 7





Step 8



Step 9



Step 10



Step 11

